

## Lexibook® Tablet Master

### Guide to Updating the Lexibook® Market Application

The Lexibook® Market application allows you to download and purchase hundreds of games and applications directly on your Lexibook® tablet.


Please follow this guide to update the Lexibook Market® application and get the most out of your Lexibook® tablet.




1. Before proceeding, please make sure that your tablet is connected to a Wi-Fi network. On the homepage of the tablet, click the “**Lexibook Update**” icon.




2. Scroll down the page until you see a purple “**Lexibook® Market**” box. Click the box to download the new version of the Lexibook® Market application on your tablet.




3. The message below indicates that the download has started. Please wait for the download to complete. Depending on your connection, this operation may require some minutes.




4. When the download is complete, the message disappears. Click the clock in the bottom-right corner of the screen, then press "Download complete" to open the downloaded file.




5. Click the file to install the new version of the Lexibook Market® application on your tablet.




6. Select "Install" to confirm the installation.



7. Please wait for the installation to complete.





8. Select “Done” to finish the installation.



9. Back on the homepage of the tablet, click the “**Lexibook Market**” icon to access the new version of the Lexibook® Market application.



10. If there is no “**Lexibook Market**” icon on the homepage, just click the “**apps list**” button  in the top-right corner of the screen and select the “**Lexibook Market**” icon.



11. Download and enjoy new games and applications!

